




# COOKTOP PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)

30" ELECTRIC CERAN  
FREESTANDING RANGE  
SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3196417	Cooktop White
	3196418	Almond

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	3149191	Spring, Locator
	3196170	Screw
5	3169397	Light, Indicator (Hot Surface)
6	3195810	Bracket, Ind Light
	3196165	Screw (2)
7		Element, Surface (Includes # 8)
	3189897	2400 W - LF
	3196428	1200 W - LR
	3189895	1700 W - RR
	3196428	1200 W - RF


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

8		Limiter, Temp.
	3190251	2400 W - LF
	3190248	1200 W - LR
	3190250	1700 W - RR
	3190248	1200 W - RF
9	3196455	Bracket, Element
	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	3186190	White Left Hand
	3186191	White Right Hand
	3186192	Almond Left Hand
	3186193	Almond Right Hand
2	3186198	Left Hand
	3186199	Right Hand


Illus. No.	Part No.	DESCRIPTION
3	3186177	White
	3186178	Almond
4	3148955	Left Front
	3148951	Left Rear
	3148952	Right Rear
	3148951	Right Front
	3196171	Screw (8)
5	313102	Light, Ind. (2)
6	3196068	Lens, Light (2)

Illus. No.	Part No.	DESCRIPTION
7	3196232	White
	3196233	Almond
8	3195212	Shield, Heat
9	4449746	Screw (4)
10	3195163	Cover, Upper
	3196178	Screw (9)
12	3195101	White
	3195102	Almond
13	3196178	Screw (2)
14	3195133	Cover, Box
	3196178	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1	3169110	Tube, Oven Vent
2	3196156	Support, Corner LR
	3196165	Screw
3		Panel, Side (2)
	3186073	White
	3186074	Almond
	3186075	Black
4	3196119	Latch, Door
	3196168	Screw (2)
5	3196128	Rod, Latch
6	3196125	Solenoid Assy.
	3196178	Screw (2)
7	3195737	Seal, Oven Flange
8	3195063	Element, Broil
	3196174	Screw (4)
9	3195067	Element, Bake
	3196174	Screw (2)
10	3195023	Seal, Oven Door
11	3196392	Spacer, Door
12	3196262	Switch, Door
13	3195546	Glide, Drawer (2)
	3196165	Screw (2)

Illus. No.	Part No.	DESCRIPTION
14	3196037	Foot, Front (2)
	3196179	Screw (4)
	3196178	Screw (2)
15	3186156	Frame, Front
16	3186145	Tray, Insulation
17	3196576	Clip, Panel (6)
18	3186055	Rail, Base (2)
	3196178	Screw (6)
19	312701	Foot, Rear (2)
20	3196091	Shield, Outer (2)
	3196177	Screw (4)
21	3196092	Shield, Inner (2)
	3196177	Screw (2)
22	3195717	Retainer, Side (2)
	3196178	Screw (4)
23	3148440	Sensor, Oven
	3196178	Screw (2)
24	3195736	Support, Front (2)
	3196165	Screw
25	3195987	Support, Corner RR
	3196165	Screw
26	3196548	Fuse, Thermal
	3196172	Screw
27	3195809	Bumper, Side (2)


Illus. No.	Part No.	DESCRIPTION
28	3186116	Support, Oven (2)
	3196165	Screw (4)
29	3186034	Bracket, Service
	3196178	Screw (2)
	112432	Nut (3)
30	4449868	Block, Terminal
	3196163	Screw (2)
31	3195707	Back, Main
	3196178	Screw (2)
32	3196437	Bracket, Flue
	3196165	Screw
33	3195931	Flue
	3196566	Screw (2)
34	3196701	Light Socket Assy
35	311255	Bulb, Oven Light
36	3196439	Button, Plug
37	3169573	Ground Strap
	112432	Nut (3)

## INSULATION

3195037	Insulation, Wrap
3186148	Insulation, Back
3196436	Insulation, Vent

# DRAWER & BROILER PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)




Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	3195996	Grill, Broiler
3	3196076	Pan, Broiler
4	3186096	Drawer, Storage
5	3186098	Bracket, Drawer(2)
6	3196168	Screw (4)
6	3196558	White
6	3196559	Almond
7	3186101	Panel, Drawer Frnt
7	3195094	White
7	3195094	Almond
9	3195062	Glide, Drawer (2)
10	3196168	Screw (8)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3195603	Trim, Door Top
	3195604	White
	3195809	Almond
2	3195809	Bumper, Door (2)
3	3196164	Screw (2)
	3195218	Handle, Door
	3195921	White
	3196161	Almond
4	3196161	Screw (2)
5	3186296	Liner, Door
6	3195985	Seal, Window
	3186282	Glass, Inner (2)

Illus. No.	Part No.	DESCRIPTION
7	3186290	Frame, Glass
8	3186256	Insulation, Door
9	3186299	Retainer, Insul.
10	3186068	Hinge, Door (2)
11	3195613	Glass, Outer Door
	3195616	White
	3195616	Almond
12	3195974	Trim, Side
	3195974	White Left Hand
	3195971	White Right Hand
	3195975	Almond Left Hand
	3195972	Almond Right Hand

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw (9)
14	3195422	Trim, Lower
	3195422	White
	3195423	Almond
15	3196025	Clip, Glass (6)
16	3195914	Bracket, Latch
17	3196168	Screw
18	3196161	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MISCELLANEOUS PARTS

For Model: RF386PXEQ0, RF386PXEZ0  
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

## SPLICING WIRES--25FT.

### LENGTH

242828	Wire, Black	12 Ga. 150° c
242820	Wire, Black	14 Ga. 150° c
242821	Wire, Blue	14 Ga. 150° c
242822	Wire, Brown	14 Ga. 150° c
242830	Wire, Brown	14 Ga. 200° c
242823	Wire, Green	14 Ga. 150° c
242824	Wire, Orange	14 Ga. 150° c
242829	Wire, Red	12 Ga. 150° c
242825	Wire, Red	14 Ga. 150° c
242831	Wire, Red	14 Ga. 200° c
242826	Wire, White	14 Ga. 150° c
242827	Wire, Yellow	14 Ga. 150° c
242832	Wire, Yellow	14 Ga. 200° c

## REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72109	New Avocado
72108	Coffee
72110	Harvest Gold
72112	Toast
72113	Platinum
**511873	White Porcelain (2 Oz.)

## PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
261888	New Avocado
261886	Coffee
261890	Harvest Gold
285365	Toast
285366	Platinum
285006	Superior Black
206922	Primer (White)

## PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
261891	Harvest Gold (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3184478	Cleaner, Glass

## ANTI-TIP KIT

3176830	Anti-Tip Kit
---------	--------------

## LITERATURE PARTS

LIT3195944	Instructions, Installation
LIT3195945	Installation Instr (Templet)
LIT3196278	Guide, Use & Care
LIT3196077	Tech Sheet

## WIRING HARNESS PARTS

3196387	Harness, Cooktop
3196520	Clip, Wire Harness
3195153	Harness, Oven
3196696	Clip, Wire Harness
3196108	Harness, Wire (Door Switch)
311227	Wire, Ground
313660	Clip, Ground Wire
3196173	Screw
3196154	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST